

TABLE OF CONTENTS

Limited or special coverages may not contain all items, but that material which is included should be arranged in the order outlined.

TABLE OF CONTENTS EH-I

REFERENCE TABLES

ALTIMETER SETTING (FLIGHT LEVEL TABLE) 3

PHONETIC ALPHABET AND MORSE CODE 4

METRIC MULTIPLES AND SUB-MULTIPLES..... 5

WIND COMPONENT TABLES 5

PRESSURE ALTITUDE 7

INCHES TO HECTOPASCALS (OR MILLIBARS)..... 9

HECTOPASCALS (OR MILLIBARS) TO INCHES..... 12

MILLIMETERS TO HECTOPASCALS (OR MILLIBARS) 14

CONVERSIONS 15

 Meters per Second to Feet per Minute 15

 Meters per Second to Knots 15

 Temperature 16

 Weight 16

 Distances..... 17

 Volume 20

NOTAMS

INTRODUCTION 31

TYPICAL NOTAM – IN THE SYSTEM NOTAM FORMAT 31

FORMAT EXPLANATION OF SYSTEM NOTAM 31

PREVIOUS NOTAM FORMAT AND EXPLANATION 32

NOTAM CODE 33

 Second and Third Letters 33

 Fourth and Fifth Letters 39

SNOWTAM

ORIGINATION AND DISTRIBUTION 43

SNOWTAM FORMAT 43

GUIDANCE FOR THE COMPLETION OF THE SNOWTAM FORMAT 44

EXAMPLE OF COMPLETED SNOWTAM FORMAT 45

DEFINITIONS OF THE VARIOUS TYPES OF SNOW 45

STANDARD TIME SIGNALS

INTRODUCTION 51

 Summary of Radio Broadcast Services 51

SHORTWAVE SERVICES – WWV AND WWVH 53

 Accuracy and Stability 54

 Time Announcements 54

 Standard Time Intervals 55

 Standard Audio Frequencies 56

 Silent Periods 56